



FREE FLOWING DIELECTRIC POWDERS

Eccostock HiK Powder is a series of granular, free flowing powders of adjusted dielectric properties. Though these standard powders are extremely low loss, materials of moderate and high loss can be supplied on special order. Eccostock HiK Powder is distinguished by having an extremely stable bulk density. When poured into a cavity, there is little striation physically or in dielectric properties; the material is extremely stable from point to point. Most of the powders are usable to temperatures in excess of 260°C (500 °F). Eccostock HiK Powder maintains consistent electrical characteristics with respect to frequency in the microwave range. These powders have also been treated to be relatively unaffected by changes in temperature and humidity. Eccostock HiK Powder is reusable.

FEATURES AND BENEFITS

- Extreme low loss
- Stable bulk density

MARKETS

- Commercial Telecom
- Security and Defense

SPECIFICATIONS

TYPICAL PROPERTIES		ECCOSTOCK HiK POWDER	
Dielectric Constant	Dissipation Factor	Approximate Bulk Density g/cc	
2.50	0.0004	1.64	
2.75	0.0004	1.77	
3.00	0.0004	1.84	
3.50	0.0004	1.97	
4.00	0.0004	2.12	
5.00	0.0007	2.21	
6.00	0.0007	2.34	
9.00	0.0007	2.55	
12.00	0.0007	2.70	

APPLICATIONS

- Eccostock HiK Powders are used to fill complex shapes and cavities for microwave experiments. Devices can be immersed in the dielectric powders to test the effect of special dielectric mediums. For example, an antenna can be immersed in Eccostock HiK Powder (K=10) and operated to simulate a re-entry plasma.
- Waveguides and cavities can be filled to test the effect of dielectric loading.

AVAILABILITY

- Eccostock HiK Powder is available in the following dielectric constants: 2.50, 2.75, 3.00, 3.50, 4.00, 5.00, 6.00, 9.00 & 12.00.
- Intermediate dielectric constants and Pack-in-Place materials (texture of damp sand) with dielectric constants between 12 and 17 with dissipation factors below 0.001 are available on special order.

INSTRUCTIONS FOR USE

- Tumble the material in its shipping container to insure homogeneity.
- Pour the material into the cavity, preferably all at one time.
- Jog the powder to a maximum density with high amplitude low frequency motion. For small to medium size fills, an amplitude of 1/4" at a frequency of one cycle per second is adequate. Two minutes per inch of cavity height is generally sufficient time to stabilize the density.

Americas: +1.866.928.8181
Europe: +49.(0)8031.2460.0
Asia: +86.755.2714.1166
www.lairdtech.com

RFP-DS-HiK Powder 112515

Any information furnished by Laird Technologies, Inc. and its agents is believed to be accurate and reliable. All specifications are subject to change without notice. Responsibility for the use and application of Laird Technologies materials rests with the end user. Laird Technologies makes no warranties as to the fitness, merchantability, suitability or non-infringement of any Laird Technologies materials or products for any specific or general uses. Laird Technologies shall not be liable for incidental or consequential damages of any kind. All Laird Technologies products are sold pursuant to the Laird Technologies' Terms and Conditions of sale in effect from time to time, a copy of which will be furnished upon request. © Copyright 2015 Laird Technologies, Inc. All Rights Reserved. Laird, Laird Technologies, the Laird Technologies Logo, and other marks are trademarks or registered trademarks of Laird Technologies, Inc. or an affiliate company thereof. Other product or service names may be the property of third parties. Nothing herein provides a license under any Laird Technologies or any third party intellectual property rights